



Wall and Mantle



22.5 & 337.5 ---- Start in Front Center

Front of Hearth


Wall and Mantle



22.5 & 337.5 ---- Start at Wall Center

Front of Hearth


Wall and Mantle



22.5 & 337.5 ---- Start in Front Left & Right

Front of Hearth


Wall and Mantle



22.5 & 337.5 ---- Start at Wall Left & Right

Front of Hearth


Wall and Mantle



31.6 & 328.4 ---- Start in Front Center

Front of Hearth


Wall and Mantle



31.6 & 328.4 ---- Start at Wall Center

Front of Hearth


Wall and Mantle



31.6 & 328.4 ---- Start in Front Left & Right

Front of Hearth


Wall and Mantle



31.6 & 328.4 ---- Start at Wall Left & Right

Front of Hearth


Wall and Mantle



45 & 315 ---- Start in Front Center

Front of Hearth


Wall and Mantle



45 & 315 --- Start at Wall Center

Front of Hearth


Wall and Mantle



45 & 315 ---- Start in Front Left & Right

Front of Hearth


Wall and Mantle



45 & 315 ---- Start at Wall Left & Right

Front of Hearth


Wall and Mantle



46.8 & 313.2 ---- Start at Wall Left & Right AND Front Center

Front of Hearth

Wall and Mantle



46.8 & 313.2 ---- Start in Front Left & Right AND Wall Center

Front of Hearth